

How to use your One Button Radio



www.onebuttonradio.com

Telephone +44 (0) 117 330 2277

Designed by

designability

Version 1.0

Contents

Introduction to your One Button Radio

Getting started

How to turn your One Button Radio On/Off

Choosing a radio station and volume

One button operation

How to use the USB audio function

I have a problem with the One Button Radio
that I cannot solve

Technical and Safety Information

Introduction to your One Button Radio

The One Button Radio is a retro looking, simple to use AM/FM Analogue Radio which has been designed for all to enjoy, including those with memory problems, poor dexterity or visual impairment.

Getting started

Connect the power cable or insert the batteries*



*Batteries are not included

Remove the front panel



Place the control knobs on the volume dial & tuning dial



How to turn your radio on/off

The One Button Radio has been designed to be controlled by one button.



The first time you use the One Button Radio you will need to select the volume to initiate power to the radio.

Once the initial volume has been set, simply push the button down and click the button into place to power on your radio. When you're finished, simply press the button once more to turn off your radio.

Choosing a radio station and volume

Step One: Turn ON the radio and select a radio frequency



Step Two: Tune the radio to your preferred station and set the volume



Step Three: Once you have selected your chosen AM/FM radio station, and you're happy with the volume, remove the control knobs



Step Four: After use the control knobs can be stored in the power compartment on the rear of the radio



Step Five: Replace the front panel



One button operation - on/off

The One Button Radio has been designed to be controlled by one button.



Simply push the button down and click the button into place to power on your radio. When you're finished, simply press the button once more to turn off your radio.

Your One Button Radio is set up and ready to use.

How to use the USB audio function

If you wish to play music via a USB, simply remove the front panel, insert the USB stick and this will override the radio and play the selected music (MP3) on the USB stick. Once finished, simply unplug the USB stick and the radio will automatically switch back to your chosen radio station.

I have a problem with the One Button Radio that I cannot solve.

If you have a problem with is not explained within the user guide, or if you are still experiencing a problem with your radio, please do not hesitate in contacting our dedicated support staff.

Please email our helpline: help@onebuttonradio.com

or telephone us: **+44 (0) 117 330 2277**

Technical and Safety Information

AC/DC Adapter input: 230V~50Hz

To reduce the risk of a fire or an electric shock, do not expose this appliance to rain or moisture.